

# R21T GN-40A GS

## Bow Pinner

21T GN-40A G.S.SS S.A.

SPARE PARTS LIST/ RICAMBI

ES 01

ESP	MACHINE CODE	MACHINE CODE	MACHINE CODE	MACHINE CODE	MACHINE CODE
1	11166.02	21166.02	31166.02	U31166.02	
DESC.	F21T GN-40A G.S.	R21T GN-40A G.S.	H21T GN-40A G.S.	U21T GN-40A G.S.	
BODY	138.633	138.656	138.683	138.693	

Code/Codice	RSP	Qty/Qtà	Description/Descrizione	Code/Codice	RSP	Qty/Qtà	Description/Descrizione
000060057		1	RING / ANELLO	000650005	R	1	NUT / DADO
000070052	R	1	BUFFER / AMMORTIZZATORE	000650008	R	4	NUT / DADO
000070068	R	1	BUFFER / AMMORTIZZATORE	000660009	R	2	WASHER / RONDELLA
000070071	R	1	BUFFER / AMMORTIZZATORE	000662006	R	1	PIN / SPINA
000080136		1	REST / APPOGGIO	000662016	R	1	PIN / SPINA
000080162.2		1	REST / APPOGGIO	000662019	R	1	PIN / SPINA
000104153		1	CYLINDER / CAMICIA	000662035	R	1	PIN / SPINA
000128090		1	COVER / COPERCHIO	000662042	R	1	PIN / SPINA
000138656		1	BODY / CORPO	000662097	R	2	PIN / SPINA
000140134		1	REMOTE CONTROL / COM.DISTANZA	000662098	R	1	PIN / SPINA
000140237		1	CAP / TESTA	000666024	R	2	SCREW / VITE
000144146		1	SLIDER / CURSORE	000666027	R	6	SCREW / VITE
000152010		2	SPACER / DISTANZIATORE	000666032	R	1	SCREW / VITE
000154039		1	ADAPTER / FONDELLO	000666107	R	3	SCREW / VITE
000164102		1	TRIGGER / GRILLETTO	000667022	R	1	SCREW / VITE
000166038	R	1	GASKET / GUARNIZIONE	000668025	R	2	SCREW / VITE
000168470.1		1	PLATE / GUIDA LINGUETTA	000668045	R	3	SCREW / VITE
000172491.1		1	LOADER / GUIDA FISSA	000668049	R	1	SCREW / VITE
000172505		1	LOADER / GUIDA MOBILE	000676001	R	1	BALL / SFERA
000184062		1	CATCH / LEVA				
000184114		1	CATCH / LEVA				
000184115		1	CATCH / LEVA				
000200058	R	1	SPRING / MOLLA				
000200145	R	1	SPRING / MOLLA				
000200174	R	1	SPRING / MOLLA				
000200176	R	1	SPRING / MOLLA				
000200178.1	R	1	SPRING / MOLLA				
000200180	R	1	SPRING / MOLLA				
000280059.3	R	1	BUMPER / PARACOLPO				
000288172		1	PIN / PERNO				
000288246		1	STUD / PERNO				
000288313		2	PIN / PERNO				
000294158		1	PLATE / PIASTRA				
000294159	R	1	PLATE / PIASTRA				
000294171		1	PLATE / PIASTRA				
000300651		1	PISTON / PISTONE				
000300717.2	R	1	DRIVER PISTON / PISTONE LING.				
000322024		1	ADJUSTER / POMELLO				
000326041.2		1	ADAPTER / PORTA RACCORDO				
000348012		5	SPACER / RONDELLA				
000348024		4	SPACER / RONDELLA				
000400290		1	SAFETY / SICURA				
000410240	R	1	PUSHER / SPINGIPUNTO				
000414112		1	SQUARE / SQUADRETTO				
000420359		1	HOLDER / STAFFA				
000420360		1	HOLDER / STAFFA				
000420362		2	HOLDER / STAFFA				
000440165		1	SLOT / TASSELLO				
000544050	R	1	SCREW / VITE				
000610017	R	1	STOP RING / ANELLO				
000622039	R	1	O-RING / ANELLO				
000622046	R	1	O-RING / ANELLO				
000622093	R	1	O-RING / ANELLO				
000622094	R	3	O-RING / ANELLO				
000622104	R	1	O-RING / ANELLO				
000622110	R	1	O-RING / ANELLO				
000622122	R	2	O-RING / ANELLO				
000622142	R	1	O-RING / ANELLO				
000622156	R	2	O-RING / ANELLO				
000622159	R	1	O-RING / ANELLO				

R=Recommended spare parts  
R=ricambi consigliati

